

Machine short-term decommissioning and restarting instructions:

Unity machines **with** Fresh Milk Unit (FMU)

To decommission the Unity with FMU complete the following cleaning steps:

1. Run the Daily Cleaning procedure.*
2. Run the Weekly Cleaning procedure.*
3. Power OFF the Main unit at the power switch.
4. Power OFF the FMU unit at the power switch.
5. Keep the FMU unit door open to prevent mildew during non-use.
6. Turn OFF the water at the installation location's tap.

* Refer to the Unity Cleaning & Care Manual (part number 1964160_05_UNITY_C&CM) for detailed instructions.



IMPORTANT:

Under all circumstances wherein the machine will be decommissioned for any amount of time, the Fresh Milk Unit must be cleaned according to the Purification cycle (see Unity Cleaning & Care Manual for instructions) and the milk container must be replaced empty and dry to prevent foul odours and milk spoilage.



Note:

When decommissioning the machine for less than two weeks, it may not be necessary to empty and dispose of the dry ingredients (powders and coffee beans). If the machine will be stored for more than two weeks, then the dry ingredients and coffee beans must be disposed of and replaced with fresh when the machine is recommissioned.

To re-start the Unity with FMU complete the following steps:

1. Turn ON the water at the installation location's tap.
2. Power ON the Main unit at the power switch.
3. Power ON the FMU unit at the power switch.
4. Refill the milk, dry ingredients and coffee beans.

Unity machines **without** Fresh Milk Unit (FMU)

To decommission the Unity without FMU complete the following cleaning steps:

1. Run the Daily Cleaning procedure.*
2. Run the Weekly Cleaning procedure.*
3. Power OFF the Main unit at the power switch.
4. Turn OFF the water at the installation location's tap.

* Refer to the Unity Cleaning & Care Manual (part number 1964160_05_UNITY_C&CM) for detailed instructions.



Note:

When decommissioning the machine for less than two weeks, it may not be necessary to empty and dispose of the dry ingredients (powders and coffee beans). If the machine will be stored for more than two weeks, then the dry ingredients and coffee beans must be disposed of and replaced with fresh when the machine is recommissioned.

To re-start the Unity without FMU complete the following steps:

1. Turn ON the water at the installation location's tap.
2. Power ON the Main unit at the power switch.
3. Refill the dry ingredients and coffee beans.